



CNC DIGITAL CUTTING MACHINE MANUAL




SHANDONG AMOR CNC MACHINERY CO.,LTD


Operating System

Step 4: Double click the left mouse button to open the software




Step 5: Change language to English






1.2 Software Operation Interface




“config...” Set default optimization options to realize one click Optimization:



1. Machine format size and type setting;
2. Different tool pen numbers corresponding to different colors;
3. Set the working mode of multi head or multi beam;
4. You can set the color of the finished graphics display to view the processing progress at any time;

5. You can check the default setting to automatically process the opened graphics.
Set the machine IP address to connect the machine;
6. Optimize the graphics;
7. Optimize the cutting edge for cutting fabric, leather and other materials;
8. Set the processing sequence, in which the common processing sequence: according to the sequence of pen number from small to large (when two or more processing tools are selected), the sequence of cutting the inside first and then the outside:



“piece order”The sequence of cutting the inside first and then the outside;

“Sp order”Cut according to the order of pen number from small to large;

“Piece order 2”The sequence of cutting the external figure first and then the internal figure;

“SP order INV”Cut according to the order of pen number from large to small;

“Define SP Order”Cut according to the customized tool pen number.